

FD-200-634E9660

FIG.1





FIG. 2

FIG. 2



BEST AVAILABLE COPY

FIG.3




FIG.4A




FIG.4B




FIG.4C





FIG. 5



BEST AVAILABLE COPY

FIG. 6A

FIG. 6A is a screenshot of a software window 61. The window has a title bar with three control buttons (minimize, maximize, close). The main content area contains a text box with the text "PERFORMANCE PENALTY 17% OFF". Below this, there is a list box containing the text "1st TRAY JAMMED". At the bottom, there is a text box with the text "COMMENTS OPERATION CONTINUED".

FIG. 6B

FIG. 6B is a screenshot of a software window 62. The window has a title bar with three control buttons (minimize, maximize, close). The main content area contains a text box with the text "PERFORMANCE PENALTY 17% OFF". Below this, there is a list box containing the text "1st TRAY JAMMED" and "COLLATOR JAMMED". At the bottom, there is a text box with the text "COMMENTS OPERATION CONTINUED".

FIG. 6C

FIG. 6C is a screenshot of a software window 63. The window has a title bar with three control buttons (minimize, maximize, close). The main content area contains a text box with the text "ERROR OCCURS". Below this, there is a list box containing the text "COLLATOR JAMMED". At the bottom, there is a text box with the text "COMMENTS OPERATION HALTED".

FIG. 6D

FIG. 6D is a screenshot of a software window 64. The window has a title bar with three control buttons (minimize, maximize, close). The main content area contains a text box with the text "PERFORMANCE PENALTY 1% OFF". Below this, there is a list box containing the text "COLLATOR JAMMED". At the bottom, there is a text box with the text "COMMENTS PRINT CONTINUED".

FIG.7A

Error type		Error class
Ink error	Paper discharge error	
No error occurs in all stages	No error occurs	No error occurs
	Error(s) occurs	Halting printing operation
Error occurs in a stage(s) with an operable stage(s)	No error occurs	Penalty in throughput
	Error(s) occurs	Halting printing operation
Errors occur in all stages	No error occurs	Halting printing operation
	Error(s) occurs	Halting printing operation

FIG.7B

Error type			Error class
Ink error	Paper transportation error in a paper feed unit(s) or in a stacking tray(s)	Paper transportation error in a collator(s)	
	No error occurs in all stages	No error occurs	No error occurs
No error occurs in all stages	Error occurs in a stage(s) with an operable stage(s)	Error(s) occurs	While printing While collating Penalty in throughput
		No error occurs	Penalty in throughput
		Error(s) occurs	While printing While collating Halting printing operation
			Halting printing operation
Error occurs in an stage(s) with an operable stage(s)	Errors occur in all stages		Halting printing operation
	Errors occur in all the stages having no ink error	Don't care	Halting printing operation
	No error occur in a stage(s) having no ink error	No error occurs	Penalty in throughput
No error occurs in all stages	Don't care	Error(s) occurs	While printing While collating Halting collating operation
			Halting printing operation
		Don't care	Halting printing operation